

(1) Is each part of the vapor collection system aligned to allow vapor to flow to the facility vapor connection or, if lightering, to the other vessel?

(2) Are the vapor collection hoses or arms connected to the vessel's vapor collection connection?

(3) Are the vessel and facility vapor connections electrically isolated?

(4) Have the initial transfer rate and the maximum transfer rate been determined?

(5) Have the maximum and minimum operating pressures at the facility vapor connection, or the vessel vapor connection if lightering, been determined?

(6) Have all alarms required by §§ 39.20–7, 39.20–9 and 39.40–3(a) of this subchapter been tested within 24 hours prior to the start of the transfer operation and found to be operating properly?

(7) Is each vapor recovery hose free of unrepaired loose covers, kinks, bulges, soft spots, or any other defect which would permit the discharge of vapors through the hose material, and gouges, cuts, or slashes that penetrate the first layer of hose reinforcement?

(8) Has the oxygen concentration of all inerted cargo tanks been verified to be 8 percent or less?

[CGD 80–009, 48 FR 36459, Aug. 11, 1983, as amended by CGD 88–102, 55 FR 25446, June 21, 1990; CGD 79–116, 60 FR 17156, Apr. 4, 1995; CGD 79–116, 62 FR 25135, May 8, 1997]

§ 35.35–35 Duties of person in charge of transfer—TB/ALL.

The person in charge of the transfer of liquid cargo in bulk, fuel oil in bulk, or bunkers in bulk shall control the transfer as follows:

(a) Supervise the operations of cargo-system valves.

(b) Commence transfer of cargo at slow rate of cargo flow.

(c) Observe cargo connections for leakage.

(d) Observe pressure on cargo system.

(e) If transfer is loading (rather than discharging), observe rate of loading to avoid overflow of tanks.

(f) Comply with 33 CFR 156.120 and 156.150.

[CGD 79–116, 60 FR 17156, Apr. 4, 1995, as amended by CGD 79–116, 62 FR 25135, May 8, 1997]

§ 35.35–40 Conditions under which transfer operations shall not be commenced or if started shall be discontinued—TB/ALL.

Cargo transfer operations shall not be started or, if started, shall be discontinued under the following conditions:

(a) During severe electrical storms.

(b) If a fire occurs on the wharf or on the tanker or in the vicinity.

§ 35.35–42 Restrictions on vessels alongside a tank vessel loading or unloading cargo of Grade A, B, or C—TB/ALL.

(a) No vessel may come alongside or remain alongside a tank vessel in way of its cargo tanks while it is loading or unloading cargo of Grade A, B, or C without permission of the person in charge of the transfer on the tank vessel.

(b) No vessel may come alongside or remain alongside a tank vessel in way of its cargo tanks while it is loading or unloading cargo of Grade A, B, or C unless the conditions then prevailing are acceptable to the persons in charge of cargo-handling on both vessels.

[CGD 79–116, 60 FR 17156, Apr. 4, 1995]

§ 35.35–45 Auxiliary steam, air, or electric current—B/ALL.

When discharging cargo from one or more barges, the towing vessel may furnish steam, air, or electric current for pumps on barges or dock, but in no case shall the cargo pass through or over the towing vessel.

§ 35.35–50 Termination of transfer operations—TB/ALL.

(a) When transfer operations are completed the valves on cargo connections on the vessel shall be closed. The cargo connections shall be drained of cargo.

(b) [Reserved]

§ 35.35–55 Transfer of other cargo or stores on tank vessels—TB/ALL.

(a) No packaged goods, freight, or ship's stores may be loaded or unloaded during the loading or unloading of cargo of Grade A, B, or C except by permission of the person in charge of the transfer of liquid cargo in bulk. No explosives may be loaded, unloaded, or